

The White Noise EM User Guide



The White Noise EM requires
3 high quality AAA
batteries,
not included.

1. The battery panel slides out from the back. The best way to remove the cover is to turn the unit over, place both thumbs on the battery cover and push. It should slide out with ease. (Note the small +/- signs show how to install the batteries correctly.)
2. Turn the ON / OFF switch (located on the front of the unit) to the **ON** position by sliding the switch to the left of the case. Turn **OFF** by sliding the switch to the right of the case.

The Use of this item in ANY media production is strictly prohibited without prior written approval from Digital Dowsing LLC.

www.digitaldowsing.com



Digital Dowsing



Using the
White Noise EM



Version 2.0

Copyright © 2006-2013

All rights reserved

For Experimental Purposes Only

Digital Dowsing LLC.
www.digitaldowsing.com

What the White Noise EM does

White-Noise EM creates a multi-tone, complex white noise that sweeps.

You won't hear the white noise. It's created as an EM field.

In a very dark room, you will see a faint red glow coming from the ovals in the face plate. These may not be visible in normal daylight or in lighted rooms.

Need Help?

E-mail us at:

help@digitaldowsing.com

- State the nature of your problem.
- Please provide detailed information about the problem, including pictures or drawings if needed.

We try to respond in 24 hours or less,
Monday – Friday 10am to 5pm.

Since 2006, Digital Dowsing has continued to lead the industry of paranormal technology. We are continually implementing innovative and fascinating ideas into new devices, built from the ground up.

All devices manufactured at our Loveland, Colorado plant in the United States.

Please visit our website,
www.digitaldowsing.com for more information.



White Noise EM Disclaimer

1. The WHITE NOISE EM is sold without any expectation. It is to be considered experimental.
2. The WHITE NOISE EM is sold as an **experimental device only**. We make no claim to the validity of the data received by these devices.
3. We make no claim as to Spirit Communications, Aliens, Ghosts or any other type of phenomena.
4. You agree not to expose children to this device, or any person who may be harmed or damaged by exposure to this device. Further, you must be over 18 and in sound mental condition.
5. As the owner of this device you are responsible for the devices use. Further, you are responsible for the safety of others who may come in contact with this device.
6. This device should not be used by children under the age of 18. Further, this device should not be used by anyone with a history of mental illness.